

## LANDSCAPE LED WALNUT PENDANT LAMP



SCENE SWITCH CONTROL- 3CT SWITCHABLE



After wiring, estimate the suction cup to the ceiling and tighten it

## WARNING

- 1. Get the best deals on 240 V General Purpose 50 Hz AC Frequency Rating
- 2. Avoid scratching the surface of the lamp and wires during installation
- 3. Never install it on a wet ceiling and wall. The environment should be ventilated and dry
- 4. Do not palce it close to acids and alkalis, containing corrosive and gas.
- 5. Cut off the power when cleaning. Can not be cleaned with water, only with dry soft cloth
- 6. Must be installed by a professional electrician